

RAPCO,inc.**REPLACEMENT AIRCRAFT PARTS CO.**

Parts for the Air Tractor

Brake Components:

Model	Brake Assy	Part Number	Description
AT-300	30-67X	RA164-03006 RA66-108 RA105-002	Disc Assembly Brake Pad Rivet
AT-301	30-89	RA164-03006 RA66-108 RA105-002	Disc Assembly Brake Pad Rivet
AT-302	30-89	RA164-03006 RA66-108 RA105-002	Disc Assembly Brake Pad Rivet
AT-302A	30-89	RA164-03006 RA66-108 RA105-002	Disc Assembly Brake Pad Rivet
AT-400	30-98C	RA164-05806 RA66-108 RA105-002	Disc Assembly Brake Pad Rivet
AT-400A	30-89	RA164-03006 RA66-108 RA105-002	Disc Assembly Brake Pad Rivet
AT-401	30-184	N/A RA66-108 RA105-002	Disc Assembly Brake Pad Rivet
AT-402	30-98C	RA164-05806 RA66-108 RA105-002	Disc Assembly Brake Pad Rivet



Brake Components cont.

Model	Brake Assy	Part Number	Description
AT-501	30-98C	RA164-05806 RA66-108 RA105-002	Disc Assembly Brake Pad Rivet
AT-502	30-98C	RA164-05806 RA66-108 RA105-002	Disc Assembly Brake Pad Rivet
AT-503	30-98C	RA164-05806 RA66-108 RA105-002	Disc Assembly Brake Pad Rivet
AT-503A	30-98C	RA164-05806 RA66-108 RA105-002	Disc Assembly Brake Pad Rivet
AT-802	30-170ALR, ARH	RA164-23000 Cle 66-131 RAPB-001	Disc Assembly Brake Pad Rivet